

# Exploded View

Screw ①×4(412-058-8400)

Screw ②×4(411-175-6504)

Screw ④×2(411-176-7005)

Screw ⑤×4(411-177-7103)

Screw ③×2(411-169-9603)

Screw ⑨×1(411-020-0701)

Front Lens Cabinet 21×1(636-053-9488)




FIG 1

- Screw ❶ × 2 (412-058-8400)
- Screw ❸ × ( 4 1 1 - 1 7 7 - 4 1 0 2 )
- Screw ❹ × 1 (411-176-7005)




FIG 2

- Screw ②×14(411-175-6504)
- Screw ⑦×3(411-175-3602)
- Screw ⑧×1(411-175-8904)
- Joint Spacer10×1(636-054-1016)



Nikon Coolpix 950 Bottom Cover Holder  
& CF Card Set

FIG 3